

GPRS/MMS/SMTP/SMS Infrared Trail Camera
User's Manual
HT-002LIG



HT-002LIG

CE FCC RoHS IP54

Table of Contents

- 1 Instructions.....2
 - 1.1 General Description2
 - 1.2 Camera Body Interfaces2
 - 1.3 Camera Components and Features.....2
 - 1.4 Shooting Information Display3
 - 1.5 MMS function.....3
 - 1.6 Supported Format.....3
- 2 Cautions.....4
- 3 Easy Operations.....5
 - 3.1 Power Supply.....5
 - 3.2 Insert the SD-card and the SIM-card.....5
 - 3.3 Power on and Enter into the ON Mode5
 - 3.4 Enter into the TEST Mode.....5
 - 3.4.1 Custom Settings.....5
 - 3.4.2 Manual Capturing.....5
 - 3.4.3 View Images or Videos.....5
 - 3.4.4 Send MMS.....5
 - 3.5 Power Off6
- 4 Advanced Operations.....7
 - 4.1 Settings Menu7
 - 4.1.1 Camera setting.....7
 - 4.1.2 Video setting.....7
 - 4.1.3 System settings.....8
 - 4.1.4 Default.....8
 - 4.1.5 General Settings.....9
 - 4.1.6 Set Camera Mode.....9
 - 4.1.7 Format SD-Card.....9
 - 4.1.8 Set Photo Size.....9
 - 4.1.9 Set Video Size.....10
 - 4.1.10 Set Date and Time10
 - 4.1.11 Set Multi.....10
 - 4.1.12 Set ISO.....10
 - 4.1.13 Set Video Length10
 - 4.1.14 Set Delay.....11
 - 4.1.15 Set Timer.....11
 - 4.1.16 MMS and GPRS Settings.....11
 - 4.1.17 Set MMS Mode.....12
 - 4.1.18 Enter Password.....12
 - 4.2 Playback.....12
 - 4.2.1 Viewing Photo or Video13
 - 4.2.2 Delete Photo or Video.....13
 - 4.3 File Numbering.....13
 - 4.4 Firmware Upgrade.....13
 - 4.5 SMS command list.....13
- Appendix I : Technical Specifications.....14
- Appendix II : Parts List15

1. Instructions

1.1 General Description

This camera with MMS/SMS Command function, is a surveillance camera working automatically. It can be triggered at once by any movement of human (or animals) in a certain region of interested (ROI) monitored by a high sensitive Passive Infrared (PIR) motion sensor, and then automatically captures high quality pictures (up to 12M pixels) or records 1080p HD video clips (WVGA or QVGA).

At sunrise the unit begins to take color photos and video until there is insufficient light (dusk) when it begins to take infrared (monochrome) photos and video.

It is easy to use, there is a 2.5 inch colorful LCD display on camera, and it supports MMS/SMTP/SMS/E-mail via 3G Network. It is resistant against water and snow for outside uses.

1.2 Camera Body Interface


The camera has the following I/O interfaces: USB connector, SD-card slot, TV output and external DC power connector.

Take a few moments to familiarize yourself following the camera controls and displays. It is helpful to bookmark this section and refer to it as you read through the rest of the manual.

1.3 Camera components and features




- 1) Test Indicator
- 3) Infrared Flash
- 4) PIR
- 5) Lens
- 6) Lock
- 7) Lock hole



- 1) 2.5 inch Color LCD Display
- 2) Power Switch
- 3) Distance Switch
- 4) Menu Switch
- 5) SHUTTER Switch
- 6) Select Switch
- 7) SD-Card Slot
- 8) USB Connector
- 9) TV Out Connector
- 10) SIM-Card Slot
- 11) Battery Depot

1.4 Shooting Information Display

When the camera is turned on (the power switch is slid to TEST position), the shooting information will be displayed in the monitor.



1.5 MMS Function

This camera can send pictures instantly to your mobile device via the GPRS network. You'll be alerted only when something has happened; The MMS through GPRS to send, so before using this function you need to make the settings in the txt file for mms or smtp. Review to related information, please refer to section 4.1 setting menu table "MMS mode" and 4.1.16 MMS and GPRS settings.

SIM card Icon: There are two SIM card icons. It means the SIM card is inserted and it works well. It means the network signal in your local place is very good. When without inserting the SIM Card or low signal strength, will disappear at the same

time.

There are 5 submenu settings about the MMS function. Including: APN, MMSC, WAP Gateway, MMS Phone, MMS Mail (refer to 4.1 table). MMS Set means to have the right MMS setting parameters according to your network. Send to means to input the phone number or email address which you want to send. All 5 submenus must have correct settings.

1.6 Supported Format

Item	Format
Photo	JPG
Video	AVI
File Format	FAT32

Here are some important notices. You don't need to concern about the file system format of the camera unless you have problems with reading the SD-card by your other equipment. If this happened, please format the SD-card in the camera or in a computer at first and then reinsert the card into your camera to make a try.

2. Cautions

The working voltage of the camera is 7.5v to 9.0V. The camera is supplied by the rechargeable lithium battery.

Please unlock the write-protect before inserting the SD-card.

Please insert the SD-card when the power switch is at OFF position before testing the camera.

Please do not insert or take out the SD-card when the power switch is at ON position.

It is recommended to format the SD-card by the camera when used at the first time.

The camera will be in USB mode when connected to a USB port of a computer. In this case, the SD-card functions as a removable disk.

Please ensure sufficient power when having firmware upgrade, otherwise the upgrade process could be interrupted incorrectly. If any fault occurs after improper upgrading process, the camera may stop function properly.

As communications networks may vary reasons we can't guarantee 100% success by sending and receiving MMS.



3. Easy Operation

3.1 Power Supply

Open the battery cover. Confirm that the power switch is at the OFF position, load the fully charged lithium battery into the depot. Push back the battery cover.

When in Test Mode, camera will be automatically shut down to save power if without any operation within 3 minutes; it could be waked up by any movement detection.

When in low-battery state, camera will be also automatically shut down. Please change the batteries in time.

If you have set the MMS function, it will send you a SMS or Email to indicate the low battery situation.

3.2 Insert the SD-card and the SIM-card

Insert SD-card into the card slot with marked side upwards.

Please note that the SD-card can only be plugged in one direction. Make sure that the write-protect switch of the SD-card is on the “write” position.

When use MMS/SMS/E-mail function, be sure to insert SIM-card into the SIM-card slot with angle in the lower left.

3.3 Power on and Enter into the ON Mode

Before switching on, please pay attention to the following:

1. Avoid temperature and motion disturbances that could be construed as animals or humans such as trees that are exposed to direct sunlight for much of the day or any other heat source. These may cause false triggers

2. The height from ground for placing the camera should 1 meter with the object. For example for deer waste height is good size appropriately. In general, one to two meters are preferred.

Slide the power switch to the ON position to power on the camera and enter into the ON mode.

After switching on the camera, the motion indication LED (red) will blink for about 15s. The 15s is a buffering time before automatic capturing photos or videos, e.g. for closing and locking the bottom cover, fixing the camera on a tree and walk away.

In ON mode, the camera will take pictures or videos automatically according to the default settings or previous custom settings. The camera has the sound recording function, so the sound will be embedded in the video clip while capturing a video.

3.4 Enter into the TEST Mode

Slide the power switch to the TEST position to enter into the TEST mode. There are some functions in TEST mode: Custom settings, manual capture, preview.

3.4.1 Custom Settings

Press the MENU switch to enter into menu setting. The camera can be taken over control to manually customize the camera settings which display on the camera or external TV monitor. The detailed operations will be described in “Advanced Operations” chapter.

3.4.2 Manual Capturing

You can press SHUTTER to manually capture photos or recording video.

3.4.3 View Images or Videos

There are two ways to view the captured images or videos:

1. LCD screen on camera
2. TV monitors which connects to camera with TV cable

Turn right the select switch to view images, the latest image will be shown in the LCD screen on camera or TV monitor. Press UP to view the previous image and press DOWN for the next. The detailed operations like deleting images or videos will be described in “Advanced Operations” chapter.

3.4.4 Send MMS

The MMS function will be available after MMS Mode is set as “Instant”, any of 1-99

photos is optimal for sending one day by GPRS network.

3.5 Power Off

Slide the power switch to OFF position to power off the camera. Please note that even in the OFF mode, the camera still consumes certain power at μA level.

Therefore, please remove the battery if the camera will not be used for a long time.


4. Advanced Operations

From the basic operations of the camera in previous chapter, we know that the camera has three basic operation modes:

- 1. OFF mode: Power switch is at OFF position
- 2. ON mode: Power switch is at ON position
- 3. TEST mode: Power switch is at TEST position

In the above three modes, the OFF mode is the specified safe mode when replacing the SD-card or batteries and transporting the camera.


This chapter explains the advanced operations for customizing the camera settings. The settings can only be customized in TEST mode.




4.1 Settings Menu

To view the camera settings menu, press MENU in the TEST mode (called settings menu in this chapter).The settings menu will be shown on the LCD on camera or the external TV monitor.


4.1.1 Photo Setting



4.1.2 Video Setting



4.1.3 System Setting



4.1.4 Default

Default Settings are listed as below:

Setting	Default	Items
Mode	Camera	Camera, Video, Camera&Video
Resolution (Camera)	12M	12M,8M,5M
Delay	5 Seconds	5-30 Seconds,1-30 Minute
Multi	Single	Single,3,6,9 Pictures
ISO	200	100,200,400
Resolution (Video)	1080P	1080P,720P,WVGA,QVGA
Video Length	10s	10s,30s,60s,90s
Date/Time	Same as last time	YY/MM/DD,MM/DD/YY,DD/MM/YY Adjust
Distance	High	High, Normal, Low
Language	English	English, French, Germany, Spanish and Russian
Timer	0 0 0 to 23 59 59	Adjust
Format	Internal Memory	Internal Memory, SD Card
TV Mode	NTSC	NTSC,PAL
GSM Mode	Instant (99)	Instant, Off
Password	Off	Off, On

4.1.5 General Settings

The operating steps are suitable for following menu items: Camera Mode, Photo Size, Video Size, Multi, Video Length, Delay, Timer and GSM Mode.

4.1.6 Set Camera Mode

There are three camera modes: Camera, Video and Camera+Video. The way to set the camera mode is via setting menu.

The following shows how to set camera mode to Video, provided that the previous option is Photo:

- a) Press MENU to display the setting menu.
 - b) Press DOWN to select Mode.
 - c) Press RIGHT to select Video.
 - d) Press down the select switch to save the current setting.
- Press MENU to cancel setting and return to info display.

4.1.7 Format SD-Card

The system will delete all images or videos stored in the SD-card after formatting, make sure that you have made a backup of important data.

- a) Press MENU to display the setting menu.
 - b) Press RIGHT to select System setting.
 - c) Press DOWN to select Format.
 - d) Press RIGHT to select SD Card.
 - e) Press down the select switch to choose Enter to enter into submenu.
 - f) Press down to select OK. OK will be highlighted.
 - g) Press OK to start formatting the SD-card. During formatting, the display screen will show a message “Please Wait” as below.
- Press MENU to cancel setting and return to info display.



4.1.8 Set Photo Size

This parameter has three values: :12MP, 8MP and 5MP. The default value is 5 mega pixels. The following shows how to set pixel size as 5M Pixel:

- a) Press MENU to display the setting menu.

- b) Press DOWN to select Resolution
- c) Press Right to select 12M Pixel
- d) Press down the select switch to save the current setting, then press menu to return to info display.

Press MENU to cancel setting and return to info display.

4.1.9 Set Video Size

This parameter also has four values: 1080P,WVGA,QVGA.

The default value is 1080P,the following shows how to set 720P video size as provided that the previous option is at WVGA :

- a) Press MENU to display the setting menu.
- b) Press DOWN to select Resolution.
- c) Press RIGHT to select WVGA
- d) Press down the select switch to save the current setting, then press menu to return to info display.

Press MENU to cancel setting and return to info display.

4.1.10 Set Date and Time

You can change the date and time of the device by setting this parameter when necessary, e.g., after every battery change. The date format is day/month/year, the time format is hour: minute: second. The valid value for year is between 2010 and 2050.

Provided that the date and time are needed to be set to November 15th, 2011 and half past ten, the steps are as following:

- a) Press MENU to display the setting menu.
- b) Press right enter into "system"
- c) Press DOWN to select Date/Time.
- d) Press Right to Display Date/Time Interface, Press UP and DOWN to change the Value
- e) Press down the select switch to save all current setting, then press MENU to return to info display.

Press MENU to cancel setting and return to info display.

4.1.11 Set Multi

This parameter affects the number of pictures taken for each triggering in the camera mode. It has four values: "1 Photo", "3 Photos" "6 Photos" and "9 photos". Its default value is "1 Photo". The following shows how to set photo burst to 3 Photos, provided that the previous option is 1 Photo:

- a) Press MENU to display the setting menu.
- b) Press DOWN to select Multi.
- c) Press RIGHT to select 3 pictures.
- d) Press down the select switch to save the current setting, then press MENU to return to info display

Press MENU to cancel setting and return to info display

4.1.12 Set ISO

This menu could only help you get a better photo at night, there are 3 values: 100,200,400.

- a) Press MENU to display the setting menu.
- b) Press DOWN to select Video Length
- c) Press down the select switch to save the current setting, then press MENU to return to info display

Press MENU to cancel setting and exit.

4.1.13 Set Video Length

The following shows how to set video length to 30 Seconds, provided that the previous value is 10 Seconds:

- a) Press MENU to display the setting menu.
- b) Press DOWN to select Video Length
- c) Press down the select switch to save the current setting, then press MENU to return to info display

Press MENU to cancel setting and exit.

4.1.14 Set Delay

This parameter means that how long the PIR (Passive Infrared motion sensor) will be disabled after each triggering in ON mode. During this time the PIR of the device will not react to the motion of human (or animals). The minimum interval is 5 seconds, it means the PIR works all the time and media is taken almost continuously. The maximum interval is 30 minutes, it means the PIR will be disabled for 30 minutes after each triggering. The default value is 5 seconds.

The following shows how to set PIR Triggering Interval Time as 1 minute provided that previous option is 5 seconds.

- a) Press MENU to display the setting menu.
- b) Press DOWN to select Delay.
- c) Press RIGHT to enter in to the interval setting.
- d) Press DOWN to select 1 minute.
- e) Press down the select switch to save the current setting, then press MENU to return to info display.

Press MENU to cancel setting and return to info display.

4.1.15 Set Timer

This parameter defines a certain time lapse in a day when The Camera can be triggered. In the rest of the time the device is shut off. The effective value of the hour ranges from 0 to 23 while the minute ranges from 0 to 59.

Provided that the camera should work from eight a.m. to five p.m., the steps are as follows:

- a) Press MENU to display the setting menu.
- b) Press DOWN to select Timer.
- c) Press RIGHT to select item, press UP or DOWN to change the value until the start time changes to 8 and the stop time changes to 17.
- d) Press down the select switch to save all current setting, then press MENU to return to info display.

Press MENU to return to previous menu.

4.1.16 MMS and GPRS Settings

There are some settings to be entered, the steps are as follows:

- 1).Put the disc into the computer
- 2).Find the gsm-info and smtp txt files from the disc
- 3).Change all the settings to be your own, you could contact your SIM-Card and email providers to get the information.
- 4).Copy the gsm-info and smtp txt files to your SD card.
- 5).Insert the SD card and SIM card to the camera
- 6).Power on and entering into the TEST Mode.
- 7).The camera will automatically find the signal and SIM card soon

A. Here is a MMS setting example for the SIM Card from China Mobile

The information of SIM-Card provider from China Mobile is:

MMS APN → CMWAP
MMS MMSC → <http://mmsc.monternet.com>
MMS Gateway → 10.0.0.172
Port → 80

The information of your phone numbers and email addresses for receiving photos are:

Phone Number → number1, number2, number3, number4
Email Address → email1, email2, email3, email4

And the gsm-info txt should be edited as:



B. Here is a SMTP setting example for reference

The information of SIM-Card provider from China Mobile is :

SMTP APN ➡ CMNET

The information of mail.qq.com is:

SMTP Server ➡ smtp.qq.com

Port ➡ 25


Send Email ➡ 12345@qq.com

Send Email Password ➡ 00000

The information of your recipient mails are:

Email Address ➡ email1, email2, email3, email4

Finally the smtp txt should be edited as



Please note that these are only examples, for more details please contact your network service provider, and 3 network provider parameters needs to be edited, PHONE and EMAIL could be added up to 4.

4.1.17 Set MMS Mode

The following shows how to set the GSM mode to Off provided that the previous option is Instant:

- Press MENU to display the setting menu.
 - Press DOWN to select GSM Mode.
 - Press RIGHT to select Off.
 - Press OK to save the current setting, then press MENU to return to info display.
- Press MENU to cancel setting and return to info display.

If you choose "Instant", you need to select how many MMS you want to send for economy consideration. You can choose 0 to 99 pictures.

4.1.18 Enter Password

If the password setting is selected as On, after switching on the camera, the LCD screen on camera will prompt to enter password. The default password is off. It can be changed where the steps are as following:

- Press MENU to display the setting menu.
- Press DOWN to select Password.
- Press Up to select On, then press Right to select 4 numbers as password
- Press OK to save the current setting, then press MENU to return to info display.
- The LCD screen will prompt to enter password next time you switch on the camera.

Press MENU to cancel setting and return to previous menu.

4.2 Playback

In playback mode, images or videos can be viewed, deleted. The images and videos can be viewed on: LCD screen on camera and TV monitor which connect to camera with

TV cable. For simplicity, operations with PC won't be introduced here.

4.2.1 Viewing Photo or Video

- a) Switch to TEST mode and enter into info display.
- b) Press right the select switch to view the latest picture (or video) in LCD screen on camera, TV monitor or Image viewer with TV-in connector.
- c) Press Left to start playing the video when viewing
- d) Press Left again to stop playing the video.
- e) Press UP to view the previous picture (or video) and DOWN for the next.
- f) Press down the select switch to return to info display.

When viewing images, the total number of all images in the SD-card and the index of the displaying image will be shown respectively.

4.2.2 Delete Photo or Video

The operations are as following:

- a) Press Right to display Photos and Videos.
- b) Press Menu to select Delete.
- c) Press right to select delete current or delete all.
- d) Press OK, Cancel and OK are prompted.
- e) Press OK to delete the image or video.

Press cancel to cancel, then press MENU and press down the select switch to return to info display

Please note that after deleting a picture or a video file, the deleted files can't be restored! Furthermore, in order to delete all the images and video clips in the SD-card, it is suggested to format the SD-card

4.3 File Numbering

Images and videos are separately saved in the pre-named folder (104MEDIA). File numbering continues by adding one to the last number for each new image or video. The saving name is like PTDC0001.JPB or PTDC0001.AVI. Through the suffix you can distinguish whether the file is an image (with suffix.jpg) or a video (with suffix.avi).

4.4 Firmware Upgrade

This camera is equipped with an automatic upgrade function for you. Upgrading is needed only when an improved firmware is available. The operations are as following:

1. Unzip the update file
2. Copy the FW18NA.bin to SD card.
3. Insert the SD card into the camera.
4. Power on the camera (Test Mode) .
5. The camera will read it and update itself automatically. When updating the camera, its screen is black.
6. The screen will light on after being finished
7. Plug out the SD card, then insert it into pc, delete the FW18NA.bin in the SD card. (If you don't do this, the camera will enter update mode when power on again).
8. Insert the SD card into the camera for its working.

4.5 SMS command list

mms/smtp need to be set on 'mode' well before using the sms command

500 take picture

(can work in both mms and smtp mode)

sim in camera will send [Capture](#) when receive ***500*** command

505 // take picture and send to the mobile who sends sms

sim in camera will send back [Start capturing...](#) after receiving the command code ***505*** and then send MMS to the phone number who sending code.

520 //check the picture quantity and battery status
(can work in both mms and smtp mode)
sim in camera will send **Total Jpg: Free Space: Battery Level:** when recieve *520* command

530 // turn on camera
(can work in both mms and smtp mode)
sim in camera will send **Start OK** when recieve *530* command

531 // turn camera to sleeping mode
(can work in both mms and smtp mode)
sim in camera will send **Stop OK** when recieve *531* command

Appendix I : Technical Specifications

Image Sensor	12 Mega Pixels Color CMOS
Memory	SD Card to 32GB
Size	158mm * 120mm * 58 mm
IR Filter	Full Automatic IR Filter
TFT Display Screen	2.5 inch
LED	Black Invisible 940nm
PIR Distance	High/Normal/Low
PIR Sensor Sight Angle	60 Degrees
PIR Sensing Distance	65ft/20m
Number of IR LED	42 LEDs
Trigger Speed	1.1second
Triggering Interval :	1 second ~ 30mins (default 1 sec)
Selectable Image Resolution:	12MP/8MP/5MP
Multiple Photo on one detection	1—9
Video Resolution	1080P/720P/VGA
File Format	JPEG/AVI
Exposure:	Auto
Device Serial No.	4 digits and 26 alphabets set by yourself
Time Lapse	1 Second ~ 24 Hours Programmable
Password Security	4 digital PIN code
Frequency Bands	GSM 850/900/1800/1900 MHz
	3G UMTS/HSPA 850/900/1900/2100
SMS Remote Control	Support
GPRS transmission	Data transfer by email
MMS to phone	1-4 phone number
MMS to e-mail	1-4 email address
Periodic shot	1Second~24Hours
Stand-by time	6Months
Operation Temperature	-30 ~+70℃/-22~+158°F
Power Supply	2000mA rechargeable li battery
Camera Socket	Yes
Water proof	IP54
Security authentication	FCC,CE,RoHS

Appendix II : Parts List

Part Name	Quantity
Digital Camera	1
9V Power charge	1
Rechargeable lithium battery	1
USB Cable	1
TV cable	1
User’s Manual	1
Solar power supply	Optional