

1. MMS table on software/menu are no point.
2. SMTP setting on camera is FTP setting on software

B. FTP Settings Operate as bellows:

1. Open FTP folder, and double-click MMSCONFIG.exe, as like **MMSCONFIG.exe**
2. Settings Menu for your requests
(Note: only setting camera mode can send picture)
3. Turn mms function off.
4. Selecting SMTP for your country and Operator(The Operator of SIM card to be inserted)
5. FTP Server setting
6. Click “Save”, the software will generate a “Parameter.dat” in same folder.(NO RENAME)
7. Copy “Parameter.dat” to SD card root.(NO RENAME)
8. Insert SD card to hunting camera SD card slot.
9. Put battery into camera
10. Insert a GSM 2G SIM card to SIM card slot, and open SIM GPRS functions.
If camera can accept SIM card, there is word “SIM” beside signal bar.
(Please confirm the SIM card is not locked by PIN)
11. Put switch to test position, and check “camera mode”, check the smtp info in menu. It shows camera can read the Parameter. dat or not. And then switch on position
12. At this time, camera screen will shut off, test light will flashing, and then camera will enter into PIR motion detection status.
13. It will take photo and send photo to ftp server when it has motion detection human body or animals.